


STEPS OF CONFIGURATION







ACTIVATE DHCP. CLICK OK.



CLICK OK






Now we connect the EBW H100 to Ethernet using broad band.

Now we connect the EBW H100 INSYS icom suit


https://connectivity.insys-icom.de/insysgui/

Use link & open INSYS icom suit login fast




Add device, Fill in all the data


Click ok.




▲ 🚇 👺 ...il (+) 12:42 12-03-2022




Open EBW H100 LOGIN







OPEN & CLICK



Click yes EBW H-100 is restated.

Your login ip address is 192.168.4.48







Download openVPNGUI SETUP & INSTALL

https://swupdate.openvpn.org/community/releases/OpenVPN-2.5.5-I602-amd64.msi



OpenVPN-2.5.5-I602-amd64.msi




openvpn-install-2.4.9-I601-Win10.exe

NEXT AGAIN OPEN INSYS Connectivity suit.


Create users for pc in INSYS connectivity suit

Steps




Vpn user login password (example:admin@123)

Click ok & save.






Click Kiran kamble files download





open vpn file download . & copy

(C:\Program Files\OpenVPN\config) past here loction




Go to home screen.




Right Click openvpn GUI select run as administrator



Shows the icon in screen right click this icon



Click connect



Enter your password



Now we are connected to vpn

Remove lan cables


Ping EBW H100

```
C:\Users\Lenovo\ping 192.168.4.48

Pinging 192.168.4.48 with 32 bytes of data:
Reply from 192.168.4.48: bytes=32 time=308ms TTL=63
Ping statistics for 192.168.4.48:
Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
Minimum = 307ms, Maximum = 309ms, Average = 308ms
C:\Users\Lenovo\
```

OPEN CHROME BROWSER & SERCH EBWH100 IP ADDRESS

192.168.4.48



Complete setup is ready.